



***moin*** action-chair




## User manual EN

- 1- Instructions on function
- 2- Castors matching the floor type
- 3- Maintenance
- 4- Cleaning

## **1 / Instructions regarding the function**

For space-saving storage, lift the rear of the shell. The recessed grip at the back of the shell makes it easier to operate. After lifting the shell, it is inclined at an angle of about 30° and held in this position by gas springs. An infinite number of chairs can now be stacked and moved together in a linear fashion. It is easier to manoeuvre smaller packages of chairs together than larger packages. To sit down, grasp the top of the shell and press the shell down into position of use.



## **2/ Adequate Castor quality for different floor types**

In the standard version the chair is equipped with soft all-round 'Move' double castors with a black no-noise pin from *Gross und Froehlich*. All castor surfaces in the "Move" collection are available upon request, for all floors types, respectively .. Here the rule applies:

- hard floor = soft castors
- soft floor = hard castors

The castors of the ***moin*** action-chairs are equipped with an automatic load-dependent brake. This means that they lock when the person stands (unloaded) so that the chair does not roll away uncontrolled. Only when the chair is loaded, i.e. when someone is sitting on it, will the brake release allowing the castors to roll freely. The castors are delivered with a standard transport protection, which is easily removed by the customer upon receipt.

## **3/ Maintenance**

The technical components are maintenance-free. Bearings are lubricated for life or designed as ungreased plain bearings.

The rubber buffer for seat support can be reordered from us after years of use in case of possible wear and can be replaced on site with a standard hexagon key. (Art.No.: E2020M6-75 Rubber Buffer Type E Ø20x20 M6/6 NR 75°Shore steel galvanized) This DIN article is also widely available as a standard article in specialist shops.

## **4/ Cleaning instructions:**

### **Cleaning *Ascot* leather cover**

The chair is upholstered with a high-quality semi-aniline leather.

#### **Dust**

Occasionally dust with a dry cloth or leather care glove, avoiding strong rubbing. Crumbs or the similar can be vacuumed off using a blunt nozzle.

#### **Liquid stain substances**

You should immediately and carefully clean up any liquid substances that

may stain the chair surface with a dry, absorbent paper towel or blotting paper. In order to avoid further damage to the impregnation of the leather, do not rub with force. Many stains disappear by themselves over time, as they are literally absorbed by the leather. Feel free to consult with us in case of any “accidents”.

### **Dried-on heavy soiling**

Prepare a weak neutral soap solution (curd soap) with lukewarm distilled water and wipe the stain with a soft cotton cloth. Gently remove the soap solution with a clean, slightly moistened cloth (also use distilled water). In order to avoid damage to the leather surface, never rub too hard. Then treat the dried leather with a gentle care emulsion from a specialized store to prevent it from becoming brittle (see below under 'Leather cleaning agents').

### **Grease and oil stains:**

Remove coarse grease stains with a paper towel. Do not treat residues for the time being, over time the stain will penetrate the leather and will no longer be visible. Dirt and grease stains should only be removed with a special leather cleaner.

### **Leather cleaning agents**

Ascot leather covers can be cleaned with a gentle leather cleaning agent. *Störiko product design GmbH* recommends [KERALUX® Lederpflege-Set P \(Item No. 3000\)](#). If you are using a suitable care product from another manufacturer, please test it on a concealed area beforehand. Feel free to consult with us in case of any “doubts”.

### **Please observe the following basic rules:**

- Never expose leather furniture to direct sunlight.
- Ensure constant humidity, i.e. never place furniture directly in front of the radiator or next to an oven.
- Regularly vacuum dust crumbs and hair with a blunt nozzle in the direction of the draft
- Only use cleaning agents and procedures recommended by the leather manufacturer *Gmelich Leder*. If necessary, have foam and upholstery cleaning carried out by a certified specialized company (in case of heavy soiling).

- Never treat leather surfaces with commercially available cleaning agents for other purposes (dishwashing detergent, all-purpose cleaner, etc.), as the leather surface will be irreparably damaged!
- Do not use solvents, cleaning gasoline, stain removers, turpentine, spirit, floor wax, shoe polish or abrasive agents!

## Cleaning fabric covers

Dust, impurities and body vapors penetrate the cover during normal use and the resulting friction can damage the fabric fibers. The cover fabric should therefore be cleaned regularly. The specifications of the respective fabric manufacturer of the selected cover apply. The respective fabric cover products are linked on our website:

(<https://www.roomtool.com/produkte/moin-action-chair>)

### **Please observe the following basic rules:**

- Never expose leather furniture to direct sunlight.
- Ensure constant humidity, i.e. never place furniture directly in front of the radiator or next to an oven.
- Regularly vacuum dust crumbs and hair with a blunt nozzle in the direction of the draft
- Only use cleaning agents and procedures recommended by the fabric manufacturer. If necessary, have foam and upholstery cleaning carried out by a certified specialized company (in case of heavy soiling).

## Cleaning of the aluminium components

(base, seat frame, armrests)

**Black coated** aluminum components: Dust or light soiling can be cleaned with a mild soap solution or glass cleaner.

**Polished** aluminum components: Please clean only with a dry microfiber cloth. Aluminum is a light metal with a soft surface, which makes it very susceptible to scratches. Never use hard brushes or metal sponges for cleaning. Marks, for example from the soles of shoes on the foot cross, can be removed with a soft, non-abrasive eraser.

## **Cleaning castors**

Remove any stubborn tangled hair carefully with scissors. Regularly remove hair and dirt from castors with a vacuum cleaner with a blunt nozzle.

## **Advice on cleaning**

If you have any questions regarding use and care, please feel free to contact us at any time:

**Störiko product design GmbH**

Godeffroystrasse 40

22587 Hamburg

[mail@roomtool.com](mailto:mail@roomtool.com)

[www.roomtool.com](http://www.roomtool.com)

T. +49 40 20 96 58 39

HRB 153814

Sitz Hamburg

Ust-IdNr. DE-814482244